





Titan Tec[®]
MAKE LIFE MORE BEAUTIFUL

CS5200



Titan Tec®
MAKE LIFE MORE BEAUTIFUL

CS5200

CS5200

Ref	Description	Part number
2	Starter Handle	TT00203
4	Spring	TT00406
5	Spring box	TT00503
6	Rope	TT00602
7	Reel	TT00703
8	Torsion Spring	TT00804
10	Ratchet	TT01008
13	Shroud	TT01304
14	Oil cap	TT01402
15	Seal oil cap	TT01501
21	Flywheel	TT02109
30	Left Crankcase	TT03013
31	Bearing 6202	TT03101
32	Dustproof plate	TT03203
34	Negative pressure nozzle	TT03401
36	Negative pressure tube	TT03601
39	Gasket, Cylinder	TT03909
40	Piston Ring	TT04014
42	Snap Ring, Piston Pin	TT04201
43	Piston Pin	TT04314
44	Piston	TT04414
45	elastic ring needle bearing	TT04501
46	Needle bearing	TT04614
47	Key 3x10	TT04701
48	Crankshaft	TT04814
49	Pin 5x10	TT04901
50	Gasket, Crankcase	TT05012
51	Right Crankcase	TT05113
55	vent	TT05502
56	sponge vent	TT05601
59	Guide chain block	TT05901
61	oil filter	TT06101
64	Bolt M8x42	TT06403
65	Plate injector	TT06503
67	oil pump	TT06701
68	sponge oil pump	TT06802
70	plate oil pump	TT07003
71	worm	TT07101
72	needle bearing	TT07214
74	Drum & sproket	TT07414
75	Spacer clutch	TT07501
76	Clutch	TT07602
79	Wooden teeth	TT07902

Ref	Description	Part number
80	Plate braker spring	TT08005
83	Braker lever	TT08304
85	Brake band connectin rod	TT08502
86	Brake band	TT08605
87	Positioning pin 3x9	TT08702
91	main spring braker	TT09101
92	Tension cover	TT09203
93	Adjusting screw pin	TT09304
97	Braker cover	TT09705
107	Fuel tank	TT10707
108	Trigger control arm	TT10804
109	rear handle cover	TT10905
110	Fuel Filter	TT11001
111	Balancer	TT11101
112	Balancer seat	TT11201
114	Fuel pipe and seat	TT11404
115	Throttle trigger	TT11504
116	Torsion spring trigger	TT11605
118	Seal fuel cap	TT11802
119	Cap fuel filter	TT11906
120	Handle	TT12007
124	Cover, Cylinder	TT12410
125	Primer	TT12501
126	Locknut	TT12608
128	Cover Filter	TT12811
130	element	TT13006
131	on/off switch	TT13104
135	muffler	TT13506
139	coil	TT13909
140	spark plug L7T	TT14002
141	cylinder	TT14114
143	gasket inlet pipe	TT14306
144	inlet pipe	TT14407
146	carb supporter	TT14604
147	damper rod	TT14703
149	Choke rod	TT14904
151	intake flange	TT15101
152	circle	TT15201
153	carb	TT15314
158	Fuel pipe	TT15801
159	Guide bar 16"	TT15902
160	Chain 16"	TT16002
161	Cover guide bar 16"	TT16103
167	starter assy	TT16710
168	gasket muffler	TT16814

Ref	Description	Part number
171	gasket carburetor	TT17108
200	Cylinder bolt M5x20	TT20002
234	Ring air filter	TT23402
235	Dustproof cover	TT23501
237	Short Damping seat	TT23703
238	Big Dustproof cover	TT23802
241	Braker assy	TT24104
242	Lever	TT24201
243	Pin 3x14	TT24301
244	Spring seat	TT24401
245	Spring	TT24501
246	Gasket washer	TT24602
247	Torsion spring brake	TT24701
248	front guard	TT24804
249	Torsion spring	TT24902
250	Hammer	TT25001
251	Hammer casing	TT25101
252	Casing front guard	TT25201
253	Muffler Lap	TT25301
255	oil seal clamp	TT25501
256	oil seal 15x35x7	TT25601
257	circlip 35	TT25701
258	Dustproof Gasket	TT25801
259	Throwout lever	TT25902
260	intake pipe	TT26002
261	intake pipe damper	TT26102
262	Choker rod seat	TT26203
263	oil seal 15x28x5	TT26301
264	Oil outer pipe	TT26401
265	oil inter pipe	TT26501
267	elastic ring	TT26703
268	anti scald tube	TT26803
269	shrink spring	TT26902
272	pin 6x28	TT27202
279	snap for air filter	TT27901
280	Gas deflector	TT28003
281	conical pressure spring	TT28102
282	conical spring seat	TT28202
283	chain blocker	TT28302
284	long damping seat	TT28401
285	double pin	TT28501
295	chain guider	TT29501
552	Ignition cap	TT55201
553	Braker cover plate	TT55301
554	Dustproof Plate	TT55401
556	Oil cap assy	TT55601