



AB1



AA1




HYUNDAI


POWER PRODUCTS

HLM48L


C




D



E



F



HYUNDAI

POWER PRODUCTS

HLM48L


Ref	Description	Part number
AA1-1	Upper Handle	HLG333F000075
AA1-2	Foam Pipe	HLG3320000000
AA1-3	Limiting Stopper	HLG3XW0000000
AA1-4	Nut	HLB2011B00000
AA1-5	Cable Fixing Clamp	HLG339X300000
AA1-6	Bolt	HLB1066B06032
AA1-7	Cable Support	HLG33H2000000
AA1-8	Brake Cable	HLG339XXA0000
AA1-9	Brake Lever	HLG3353N00075
AB1-1	Lower Handle	HLG33B4000075
AB1-2	Rope Guide	HLG33K0000000
AB1-3	Nut	HLB2011B00000
AB1-4	Bolt	HLB1087W08032
AB1-5	Nut	HLB2009W00000
AB1-6	Handle Plug	HLG33J0000000
AB1-7	Flat Washer	HLB5019W00000
AB1-8	Knob	HLG33C1100010
AB1-9	Bolt	HLB1088W08050
C-1	Engine	HLY52D0000079
C-2	Bolt	HLB1077W08025
C-3	Flat Key	HLBE001W00000
C-4	Blade Adapter	HLG353XX00000
C-5	Blade Washer	HLG3520000000
C-6	Blade Bolt	HLB1001B00032
C-7	19" Blade	HLG4510000000
C-8	Engine cover	HLY2A14000010
C-9	Screw	HLB3034B00000
C-10	Filtering Net Duct of Fuel	HLY28E0000000
C-11	Oil Pipe Circlip I	HLY28K0000000
D-1	Height Adjustment Plate	HLG34BD000000
D-2	Bolt	HLB1036W08015
D-3	Nut	HLB2028W00000
D-4	Right Bracket	HLG42B0000000
D-5	Left Bracket	HLG42C0000000
D-6	Deck	HLG4213000079
D-7	Mulching Plug	HLG46MN000000
D-8	Cable Sleeve	HLG52E0000000
D-9	Washing Linker	HLG62D1000000
D-10	Screw	HLB3044W00000
D-11	plug	HLG32K0000000
D-12	Rear Cover Spring	HLG36J0000000
D-13	Rear Cover Shaft	HLG36E0000000
D-14	Rear Cover Support	HLG32J0000000
D-15	Bolt	HLB1059W06014
D-16	Nut	HLB2008W00000

D-17	Rear Cover Pedestal	HLG42A0000010
D-18	Rear Cover	HLG46B0000079
D-19	Nut	HLB2007W00000
D-20	Bolt	HLB1053W05012
D-21	Side Discharge Cover Spring	HLG3271000000
D-22	Screw	HLB3036W00000
D-23	Cover Plate	HLG328CX00000
D-24	Spring	HLG328D000000
D-25	Lock	HLG328B000000
D-26	Side Discharge cover	HLG428AX00000
D-27	Side-Discharge Guiding Board	HLG4290000000
D-28	Side Discharge Cover Shaft	HLG3260000000
D-29	Side Discharge Bracket	HLG4250000000
D-30	Washer L	HLG52F0000000
D-31	Washer R	HLG52G0000000
D-32	Screw	HLB3044W00000
D-33	Front Plastic Face	HLG4241000010
D-34	Front Plastic Face Handle	HLG4241100073
E-1	Height Adjustment Handle	HLG3420000010
E-2	Spring Washer	HLB6009B00000
E-3	Nut	HLB2017W00000
E-4	Bolt	HLB1058W06012
E-5	Nut	HLB2008W00000
E-6	Height adjustment Spring	HLG34AX100000
E-7	Nut	HLB2016W00000
E-8	Split Pin	HLBB004W00000
E-9	Bolt	HLB1053W05012
E-10	Nut	HLB2007W00000
E-11	Shaft Sleeve	HLG349X000000
E-12	Bush	HLG4CT0000000
E-13	Height adjustment connecting Rod	HLG4410000100
E-14	Shaft Sleeve	HLG34DP000000
E-15	7" Wheel Cover	HLG24R2000073
E-16	10" Outer Wheel Cover	HLG34V0000073
E-17	7" Wheel	HLG24F0000000
E-18	10" Wheel	HLG34L00N00000
E-19	Rear Wheel Shaft	HLG3490000300
E-20	Front Wheel Shaft	HLG645A000000
E-21	Inner Wheel Cover	HLG34ACN00000
E-22	Bolt	HLB1058W06012
E-23	Flat Washer	HLB5031W00000
F-1	Metal Bracket	HLG4661200000
F-2	Flat Washer	HLB5032W00000
F-3	Screw	HLB3022W00000
F-4	fixed plate	HLG4661300000
F-5	Plastic Cover	HLG4661110079
F-6	Cover Plate	HLG3661120079
F-7	Handle cover	HLG4661130079
F-8	Indicated Board	HLG4661120079
F-9	Fabric bag	HLG1805G46000

HYUNDAI

POWER PRODUCTS

Y196V



HYUNDAI

POWER PRODUCTS

Y196V

Ref	Description	Part number
1	Screw	HLB3034B00000
2	Engine cover	HLY2A14000010
3	Nut	HLB2012W00000
4	Recoil Start	HLY2A2X000000
5	Blower Housing	HLY2A33000079
6	Circlip of Gear shaft	HLY3620000000
7	Bolt I	HLY3A70000000
8	Bolt II	HLY3A80000000
9	Bolt III	HLY3A90000000
10	Nut	HLB2015W00000
11	Start-up Hub	HLY3A50000000
12	Fan	HLY3A60000000
13	Flywheel	HLY3B10000000
14	Bolt	HLB1058W06012
15	Cover Plate	HLY3260000000
16	Gasket of Respirator Cover	HLY3240000200
17	Valve Element	HLY3230000000
18	Lubricate Filtering Net	HLY2220000000
19	Bolt	HLB1057W06010
20	Back plate	HLY3AAX000000
21	Bolt	HLB1067W06035
22	Brake Assy	HLY3710000100
23	bush	HLY37X0000000
24	Bolt	HLB1064W06025
25	Ignition	HLY2B20000000
26	Left plate	HLY3AA0000100
27	Gasket of Cylinder Head Cover	HLY3120000000
28	Locating Pin	HLY2260000000
29	Inlet valve	HLY3520000000
30	Outlet valve	HLY3530000000
31	Spark Plug	HLY2B30000000
32	Gasket of Muffler	HLY2930000000
33	Muffler Assy	HLY3910000000
34	Muffler Cover Assy	HLY3920000000
35	Nut	HLB2016W00000
36	Handspike	HLY55C0000000
37	Handspike Assy	HLY35E0000000
38	Rocker Support Bolt of Valve	HLY2580000000
39	Oil Seal	HLBC011H00000
40	Spring of Valve	HLY3540000000
41	Spring Coil of outlet Valve	HLY2560000000
42	upper cap of outlet Valve	HLY25D0000000

43	Spring Coil of outlet Valve	HLY2550000000
44	Rocker of Valve	HLY2570000000
45	Adjust Nut of Valve	HLY2590000000
46	Combined Nut	HLY25A0000000
47	Bolt	HLB1080W08050
48	Gasket of Cylinder Head Cover	HLY2130000000
49	Cylinder Head Inner Cover	HLY3140000000
50	Cylinder Head Outer Cover	HLY3150000000
51	Bolt	HLB1059W06014
52	Cylinder Head Assy	HLY3110000000
53	Bolt	HLB4002W06092
54	Paper Gasket of Inlet Pipe	HLY3810000000
55	Air Inlet Pipe	HLY3820000000
56	Paper Gasket of Carburetor	HLY3830000000
57	Carburetor	HLY585A000000
58	Paper Gasket of Air Filter	HLY2840000000
59	Primer	HLY28P0000050
60	Circlip	HLY28R0000000
61	Primer	HLY28Q0000000
62	Air Filter Pedestal	HLY2870000000
63	Exhuast Pipe $\phi 8 \times \phi 12 \times 165$	HLY38A0000000
64	Washer	HLB5027B00000
65	Paper Filter Element	HLY3880000000
66	Filter Element	HLY28C0000000
67	Air Filter Upper Cover	HLY2860000000
68	Fuel Tank Cap	HLY28H0000000
69	Seal Gasket of Fuel Tank Cap	HLY28F0000000
70	Connecting Rope	HLY28T0000000
71	Bolt	HLB1063W06022
72	Gasket	HLY28S0000000
73	Fuel Tank	HLY38D0000000
74	Right Bracket of Fuel Tank	HLY38NX000000
75	Nut	HLB2008W00000
76	Left Bracket of Fuel Tank	HLY38MX000000
77	Filtering Net Duct of Fuel	HLY28E0000000
78	Oil Pipe Circlip I	HLY28K0000000
79	Oil Pipe	HLY38J0000000
80	Oil Pipe Fixing Clip	HLY28U0000000
81	Oil Pipe Circlip II	HLY28L0000000
82	Crankcase	HLY5210000000
83	Speed Regulator Rocker Spindle	HLY3660000000
84	Flat Washer	HLB5026W00000
85	Oil Seal	HLBC006B00000
86	Springness Split Pin	HLY2670000000
87	bush	HLY27X0000000
88		HLY269X000100
89	Bolt	HLB1060W06016
90	Handspike of Valve	HLY56B0000000
91	Spring of Valve	HLY36C0000000
92	Bolt	HLB1085W06023

93	Speed Regulator Rocker	HLY3680000000
94	Speed Regulator Spring	HLY36A0000300
95	Oil Seal	HLBC004B00000
96	Ball Bearing	HLB0008W00000
97	Crankcase	HLY541A000000
98	Connecting Rod Assy	HLY5470000000
99	Circlip of Piston Pin	HLY5490000000
100	Piston Assy	HLY5420000000
101	Piston Pin	HLY5480000000
102	Scraper Ring	HLY5450000000
103	Bushing Ring	HLY5460000000
104	Piston Ring II	HLY5440000000
105	Piston Ring I	HLY5430000000
106	Gasket of Gear	HLY34A0000000
107	Gasket of Crankcase	HLY3350000000
108	Lubricating Gauge	HLY3331200000
109	"o" Ring $\phi 20 \times \phi 2.3$	HLBD006B00000
110	Lubricating Pipe	HLY3320000000
111	Locating Pin of Crankcase	HLY2360000000
112	Locating Pin of Crankcase	HLY3360000000
113	"O" Ring $\phi 21 \times \phi 2.3$	HLBD004H00000
114	Draining Oil Bolt	HLB1016W10012
115	Draining Oil Bolt Gasket	HLB5021W00000
116	Crankcase Cover	HLY3310000000
117	Oil Seal	HLBC008H00000
118	Tappet	HLY25B0000000
119	Camshaft	HLY5510000000
120	Gear Shaft Hold-down Plate	HLY2650000000
121	Sliding Sleeve	HLY2640000000
122	Gear Shaft Assy	HLY2610000000